



Evo Force1 Quick Guide

IMPORTANT CUSTOMER INFORMATION

bluepeak Account Number _____

WiFi Network _____


WiFi Password _____


bluepeak TV Email _____

bluepeak TV Password _____

Other _____


1. Force1 Main Menu

- You can easily access popular destinations from the Main Menu, like the Home Screen, Guide, Shows, Movies, and Apps.
- Press the TiVo button  on our remote control to get to the main menu.




2. The Home Screen

- The Home screen is your hub for finding great content to watch. Browse categories like Sports, News, Kids, and Popular Shows, or check out live sports or shows on now.
- When you find something you like, select it to see the details, watch it, or set up a recording.



3. Remote Control Button Explained

GET TO KNOW YOUR REMOTE CONTROL





Customer Care 1-888-975-4BLU | mybluepeak.com